

- 1. The control panel is recessed into the mechanical wall at the entry end of the air shower.

 2. The air shower is shipped knock down into (5) walls, (2) roofs and (2) doors.
- 3. The air shower is supplied with a sleeved penetration through the roofsection for installation of a sprinkler head. Sprinkler is by others.
- 4. The air shower does not have a floor. It uses the existing floor.



 $PO\,Box\,427$ Rancho Cucamonga, CA 91729-0427 Voice: (800) 913-0054 Fax: (909) 483-1801

Drw# LT8496RA	Title: MODEL "LT" AIR SHOWER	
Sheet:	Project:	Date:

LEGEND BLW-SHP DIRECT DRIVE PADDLE WHEEL BLOWER 1550 CFM @ 6" S.P. CLS-COMMERCIAL DUTY DOOR CLOSER DIS-NON-FUSED DISCONNECT SWITCH FOR CONTROL PANEL EMO-EMERCENCY STOP SWITCH FRAME DOOR (ENTRY END) DR2-CLEAR ANODIZED ALUMINUM FRAME DOOR (EXIT END) E1 1-sao 96%, 3 MICRON HEPA EI TER

FLI=99.9% @ .3 MICRON HEPA FLITER
FLX=8" DIAMETER FLEX CONNECTION FOR RETURN AIR
GLS=0.25" THICK CLEAR TEMPERED GLASS
GRL=RETURN AIR GRILLE

GRL-RETURN AIR GRILLE
HING-45 **NICKEL PLATED BUTT HINGE
LGT-LED LIGHT FIXTURE
MOT-54PD IBROTE OPEN DRIP PROOF MOTOR 3500 RPM
MOT-54PD IBROTE OR WING OPEN DRIP PROOF MOTOR 3500 RPM
NOZ-0.975**DIAMETER WHITE PLASTIC AIR NOZZLE (60 IN WALLS & 12 IN CEILING)
PL1-PLEPA FILTER PLENUM 0.50**THICK ALUMINUM CONSTRUCTION
PL2-RETURN AIR PLENUM 0.50**THICK ALUMINUM CONSTRUCTION
PRIL-MEM 7- PAIN FILTER
PRE-MERCY 7-PAIN FILTER
STP-PEMKO #285CFM DOOR SEALS.
SWP-PEMKO #307AV DOOR SWEEP